

Worried about someone cooking safely?

Let HomeSenser turn OFF the stove for someone who forgets.

What is a HomeSenser?

HomeSensers are devices designed to shut-off appliances even when we don't! It offers peace of mind for those of us trying to live independently. In addition, it allows us and our neighbors to live in a safer environment. Let the HomeSenser remind us to stay near the kitchen when cooking, but turn off the appliance if we forget.



How it works: 4 Distinct Stages of Operation



Stage 1 - Ready (GREEN light)
> Stove is off.



Stage 2 - Normal Cooking (YELLOW light)
> Stove is turned on (actively cooking). If stove top or oven is left alone for 6 min, will flash red. Stage 3 begins.



Stage 3 - Warning (Flashing RED light)
> Stove is on (alone). A courtesy alert sounds on and off for 2 minutes to remind you to return to the stove. If someone returns, normal cooking continues. If not, Stage 4 begins.



Stage 4 - Shut Down (RED light)
> Stove power shuts off automatically (turn stove off to go to Stage 1).

**HomeSense**
ENTERPRISES, LLC

ORDER BY CALLING:

TOLL FREE:

1.877.785.9901

OR ON-LINE:

www.HomeSensers.com