

Stage 1 - Ready (GREEN light)

- > Stove is off
- > **Display light is GREEN**



Stage 2 - Normal Cooking (YELLOW light)

- > Stove is turned on
- > **Display light is YELLOW**
- > Timer counting down to 6 minutes
- > Timer resets as long as someone checks the stove within 6 min.
- > **Display light flashes YELLOW** when stovetop or oven temperature is cycling and when you turn the stove off.
- > If the timer counts down the 6 min. (no one is in front of the stove for 6 min.) Stage 3 begins



Stage 3 - Warning (Flashing RED light)

- > Stove is on
- > **Display light flashes RED/Alert sounds**
- > Timer counts down another minute
- > Alert sounds every 10 seconds for one minute
- > If someone returns to the front of the stove, Stage 2 returns
- > If stove is turned off, Stage 1 returns with flashing YELLOW light
- > If the timer reaches a total of 8 minutes, Stage 4 begins



Stage 4 - Shut Down (RED light)

- > Stove power shuts off automatically
- > **Display light is RED**
- > Turn stove off to return to Stage 1 - Ready

